



Quick User Guide Basic Phone Operation

For detailed information please Contact: CANQUEST COMMUNICATIONS 235 St Clair St. Chatham ON N7L 3J8 519-351-1565 support@canquest.com www.canquest.com

Key	Call Features
*67	Block Caller ID (per call). Dial "*67"
	+ " number ". No dial tone is played
	in the middle.
*72	Call Forward: Dial "*72" and then
	the forwarding number followed by
	"#". Wait for
	dial tone and hang up. (dial tone
	indicates successful forward)
*73	Cancel Call Forward. To cancel
	"Call Forward", dial "*73", wait for
	dial tone, then hang up.
*98	Accessing Voice Mail. Dial *98 then
	follow the prompts.
**	Redials last number entered.

CALL FORWARD

- All incoming calls will be forwarded.
- 1) Pick up your phone.
- 2) After hearing the dial tone, input (*72), listen
- to prompt then forwarding number then (#) or
- wait for time out
- 3) Wait for dial tone and hang up.
- 4) Dial (*73) to cancel Forward.

CHECK VOICEMAIL

1) Dial *98
 2) Press 1 for "Voicemail"
 3) Press 2 to listen
 4) Press 7 to delete

SETUP VOICEMAIL

Dial *98
 Press 3 to go into "Personal Options"
 Press 3 to go into "Greetings"
 Press 2 to go into Personal Message
 Press 2 to record your own message
 Press # to finish recording
 Press # to confirm
 Hang up handset, voicemail is now setup.

REMOTE ACCESS VOICEMAIL

Access your voicemail anywhere, any time
1) Dial 1-866-290-9003
2) Enter your account number (1+ 10 digits of your phone number), followed by #.
3) Enter your PIN, followed by # .

TROUBLESHOOTING

If you do experience any issues with the phone quality, or if you're not getting dial tone, there are a few things you can try yourself.

Please Try this First

- First is unplug your router, and our phone ATA (shown in the diagram below). Wait 1 to 2 minutes. Plug the units back in and wait one or two mins for reboot to occur. After that try the phone again.
- If there is still no dial tone after step 1, it is best to contact Canquest for further assistance.

Contact Number: 519-351-1565



Phone ATA